



Bluetooth Headphone Transmitter Instructions



Use the Bluetooth Headphone Transmitter to send audio from your Synapptic USB Playback Speaker to wireless Bluetooth headphones or ear pods.

This transmitter is only needed if you're using wireless Bluetooth headphones. For wired headphones, simply plug them directly into the speaker's 3.5mm headphone socket.

These instructions are a large-print summary. Please refer to the original product instructions for full technical details and safety information.

1. A quick tour of the device

The Bluetooth headphone transmitter is a compact unit, measuring approximately 2 inches long, 1 inch wide, and half an inch deep. At one end, there is a short wire with a 3.5mm male headphone plug, which connects to your Synapptic USB Playback Speaker. The opposite end features a USB-C port used for charging the device. On the top surface, you'll find the main function button, which can be identified by a small foam

bump for easy tactile recognition. On one side of the device, there is a small switch that allows you to select between transmit and receive modes. For sending audio to Bluetooth headphones, this switch should be set to transmit.

2. Charging

The Bluetooth Transmitter contains a built-in rechargeable battery. To charge it, plug the supplied cable into the USB-C socket at the end of the device. Connect the other end of the cable - the larger rectangular USB-A plug - into a suitable USB mains charger. A charger is not supplied with the transmitter, but one can be purchased separately if needed. The transmitter takes around 2 hours to fully charge and provides up to 28 hours of use on a single charge.

3. Pairing headphones / ear buds for the first time

Before you can use your Bluetooth headphones or ear buds with the transmitter, they must first be paired. Pairing lets the transmitter know where to send the speaker's audio. Once paired, the transmitter will remember the connection and automatically reconnect when both devices are powered on and within range.

First, make sure the small switch on the side of the transmitter is set to the transmit position - this is the direction away from the short wire with the 3.5mm plug.

To begin pairing, press and hold the function button (on the top of the device) for 3 seconds to turn on the transmitter. The light surrounding the button will begin flashing blue and red, indicating that the device is ready to pair.

Next, place your Bluetooth headphones or ear buds into pairing mode. (Refer to the instructions for your specific headphones or ear buds if you're unsure how to do this.)

Once pairing is successful, your headphones may say they've connected to UGGREEN-CM672, or the light on the transmitter will switch to a slow, steady blue flash, showing the connection is complete.

4. Day-to-day use

To use the transmitter, press and hold the function button on the top of the device for 3 seconds. The light around the button will briefly flash blue to show the transmitter is powered on.

Next, plug the transmitter's 3.5mm headphone plug into the headphone socket on the back of the Synapptic USB Playback Speaker. This is the small round socket located opposite the oval-shaped charging socket. It may be labelled AUX.

Switch on your Bluetooth headphones or ear buds. If they were previously paired, they will automatically reconnect to the transmitter. You can now use your speaker as normal and enjoy the audio through your Bluetooth headphones.

To turn off the transmitter, press and hold the function button again for 3 seconds. The light will briefly flash white, then the device will power off.

5. Advanced features

If needed, the transmitter can connect to two pairs of Bluetooth headphones or ear buds at the same time, allowing you to share the audio with someone else.

To pair a second set, first power on the transmitter. Then quickly press the function button twice. The light will start flashing blue and red again. Follow the same pairing steps as before to connect the second set of headphones or ear buds.

If you ever need to reset the transmitter and remove all previously paired devices, power it off first. Then press and hold the function button for 10 seconds. The light around the button will flash red, green, and blue, indicating that the reset is complete.

You're now ready to enjoy wireless listening using your Bluetooth headphones and the Synapptic USB Playback Speaker.

6. Need help?

If you experience any issues, double-check that:

- The transmitter is fully charged and set to transmit mode
- Your headphones are powered on and in range
- The 3.5mm plug is securely connected to the speaker

For more help, refer to the full instruction leaflet included with the transmitter, or contact Synapptic Support at **help@synapptic.com** or telephone us on **0191 909 7 909**.